

## What Size Do I Need?

It's easy to order the correct size. Simply measure your car from bumper to bumper and from outside of tire to outside of opposite tire. Add 6" to your overall length and this is the correct size you will need to order."

**Example:** 1965 Ford Mustang is 181.6" Long + 6" = 187.6" or 15.63' Order a CC16

**Example:** 2008 Chevrolet Camaro LS is 190.4" Long + 6" = 196.4" or 16.36' Order a CC18